HUBER+SUHNER® SENCITY® OMNI ANTENNA



FOR WIRELESS COMMUNICATION

Mounting Instruction



Keep away from catenary and high voltage lines. Be careful when working at height! Always secure ladders! Always tighten screws!

If exposed to extreme environmental conditions, especially polluted atmosphere, the connectors should be covered with a self-vulcanizing tape or a cold shrink tube.



Omni directional antenna

The antenna package (cardboard box) contains:

- 1 antenna
- 1 fixing kit (containing 1 bracket, 2 hose clamps)
- 1 Mounting instruction DOC-0000456327

INSTALLATION INSTRUCTIONS

- **STEP 1:** Attach the bracket to the antenna using washer and nuts as shown. Use tightening torque of 3.5 Nm.
- **STEP 2:** Insert the clamps into the bracket and tighten it to the pole. Use tightening torque of 4 Nm.




Fig.1

MAINTENANCE AND REPAIR

The antenna is maintenance free and does not need any regular maintenance. If the antenna fails it cannot be repaired in the field. In this case it is required to return it to the supplier.

HUBER+SUHNER is certified according to ISO 9001 and ISO 14001

WAIVER!

It is exclusively in written agreements that we provide our customers with warrants and representations as to the technical contained specifications and/or the fitness for any particular purpose. The facts and figures herein are carefully compiled to the best of our knowledge, but they are intended for general informational purposes only.

HUBER+SUHNER – Excellence in Connectivity Solutions



HUBER+SUHNER AG RF Technology 9100 Herisau, Switzerland Phone +41 (0)71 353 41 11

Phone +41 (0)71 353 41 11 Fax +41 (0)71 353 47 51 www.hubersuhner.com

Doc. No. DOC-0000456327 Art. No. 92000388 Revision A